



UDB-A  
USB-A

## FIELD OF APPLICATION

- for vented pitched roofs
- high quality protection for wood and insulation
- for installation directly on thermal insulation or wood sheathing

## ADVANTAGES

- rain-tight, wind-tight
- UV-stabilized
- 100% recyclable
- easy to cut
- anti-glare
- anti-slip

## RECOMMENDED ACCESSORIES



**OMEGA** QUILLI



**OMEGA** Nail-Seal Tape



PE Nail-Seal Tape DSK







# OMEGA 180 Underlay

An extremely diffusive roof underlay for installation directly on the thermal insulation or wood sheathing. Raintightness prooved by Holzforschung Austria. (Report no. : 301/2003/2-T/HH).

## AVAILABLE IN THE FOLLOWING DIMENSIONS

Roll width	1,50 m	2,50 m	3,0 m
Roll length	50 m	50 m	50 m
Roll area	75 m <sup>2</sup>	125 m <sup>2</sup>	150 m <sup>2</sup>
Roll weight	16 kg	22,5 kg	27 kg

## PRODUCT DATA ACCORDING TO STANDARD EN 13859-1 / EN 13859-2

Composition	3-layer PP fleece	
Thickness	0,72 mm	
Colour	grey	
Weight per unit area	180 (±10) g/m <sup>2</sup>	
Sd - value	0,025 m (+ 0,035/- 0,01)	
Temperature resistance	- 40 °C - + 80 °C (short-term 100°C)	
UV - resistance	4 weeks	
Resistance to water penetration EN 1928	W1	
Elongation EN 12311-2	 35 - 70 %	 50 - 90 %
Tensile strength EN 12311-2	 370 (- 60) N/50 mm	
	 260 (- 50) N/50 mm	
Tear propagation resistance EN 12310-1	 230 (- 50) N	 230 (- 50) N
Storage	cool and dry	
Fire performance EN 13501-1 / EN 11925-2	E	

04.2018\_EN

# ISOCELL

# GUIDELINES FOR INSTALLATION OF **OMEGA** ROOF UNDERLAY

## (1) UNDERLAY (unsupported)

OMEGA roof underlay is nailed parallel to the eaves with a slight drape and laid and mechanically fixed above the rafters. Vertical overlaps/joins must always lie on a rafter. All overlaps must be bonded with OMEGA Quili. Horizontal underlay panels can be joined using SK-DUO's adhesion as provided or with OMEGA Quili. (no pressure need be applied).

## (2) UNDERLAY (supported)

OMEGA roof underlay is laid on sheathing parallel to the eaves. The blankets are fixed with concealed nails spaced at 10 cm at the ridge-side edges (marks at edge). All overlaps/joins must be bonded with OMEGA Quili (without applying pressure) or the integrated adhesive strips (applying adequate pressure). For the raintight version (temporary cover) a nail-seal under the counter batten (OMEGA Quili or OMEGA Nail-seal Tape) is necessary. The single-sided nail-seal tape must be attached to the roof underlay directly beneath the counter batten!

## (3) EAVES CONSTRUCTION

We recommend an eaves construction with drainage below the gutter so that snowmelt build-up can easily drain off. We recommend the use of a metal sheet to drain off water.

## (4) RIDGE AREA

The ridge area is closed directly when covered with OMEGA roof underlay. This provides immediate protection against water penetration. In non-insulated lofts and/or ventilated interior insulation the ridge formation must be made open: the blankets end 3 cm before the ridge apex, counter battens are mounted and a 50 cm wide strip of OMEGA roof underlay must be attached over the roof apex.

## (5) VALLEY FORMATION

The first step in valley formation is to lay a continuous valley blanket.




## (6) PENETRATIONS

Sections cut out for roof penetrations (extractor pipes, roof windows, chimneys, etc.) should be kept as small as possible and the ends of the sheets must be fixed so that no rain or snow can penetrate. To achieve a perfect seal the appropriate sealing tapes and sleeves supplied by ISOCELL GmbH must be used.

*Make sure that the substrate is clean! The manufacturer can accept no liability for mechanical damage. The applicable regulations and guidelines (e.g. of the ZVDH (Central Association of German Roofers) for Germany, Austrian Standard, ÖNORM B 4119, for Austria, ...) must be observed!*

*Wood preservatives can influence the impermeability of the underlay. Do not hesitate to contact our applications engineers who are always pleased to provide information!*

*The roof underlay does not replace roof covering. The roof must be covered during the period of the specified weathering time. Early covering has a positive effect on the resistance to ageing.*



ISOCELL GmbH  
Gewerbestraße 9  
5202 NEUMARKT AM WALLERSEE | Österreich  
Tel.: +43 6216 4108 | Fax: +43 6216 7979  
office@isocell.at

ISOCELL SCHWEIZ AG  
Herbergstrasse 29  
9524 ZUZWIL | Suisse /Schweiz  
Tel.: +41 71 544 47 20  
office@isocell.ch

ISOCELL FRANCE  
170 Rue Jean Monnet | ZAC de Prat Pip Sud  
29490 GUIPAVAS | France  
Tél.: +33 2 98 42 11 00 | Fax: +33 2 98 42 11 99  
contact@isocell-france.fr

ISOCELL BUREEL BELGIË  
Außenborner Weg 1 | Schoppen  
4770 AMEL | Belgique  
Tel.: +32 80 39 90 58 | Fax: +32 80 39 97 68  
office@isocell.be

ISOCELL Sverige AB  
Box 20059  
161 02 BROMMÅ | Sverige  
Tel.: +46 10 130 25 00  
info@isocell.se

**ISOCELL**  
www.isocell.com